



Application Descriptions

7

HVAC ObIS

19

Continuous Valve Actuator

7

Summary

This object is used to control continuous actuating valve positioners e.g. for hot water heating radiators.

Version 01.00.01 is a KNX Approved Standard.

This document is part of the KNX Specifications v2.1.

Document updates

Version	Date	Modifications
1.0	2002.04.03	Editorially restyled: based on " 18-01_ObIS_OVA.doc"
1.0	2009.06.15	Editorial update in view of inclusion in the KNX Specifications v2.0.
01.00.01	2013.10.29	Editorial updates for the publication of KNX Specifications 2.1.

References

None.

Filename: 07_19_07 ObIS CVA v01.00.01 AS.docx
Version: 01.00.01
Status: Approved Standard
Savedate: 2013.10.29
Number of pages: 13

Contents

1	Proposed Application Model(s).....	4
2	ObIS Function Model(s)	5
2.1	ObIS Function Model "Continuous Valve Actuator"	5
2.1.1	Aims and objectives.....	5
2.1.2	Functional specification	5
2.1.3	Constraints	5
2.1.4	Functional Block.....	5
2.1.5	Properties	7
3	Datapoint Type(s).....	12
3.1	Datapoint Type "Boolean"	12
3.2	Datapoint Type "CVA Status"	12
3.3	Datapoint Type "8-bit unsigned multiplier with special function for zero"	13

1 Proposed Application Model(s)




Figure 1 - Example for Individual Room Temperature Control with Heating and Cooling with ON/OFF Control




Figure 2 - Example for Individual Room Temperature Control with Heating and Cooling with PI Control

2 ObIS Function Model(s)

2.1 ObIS Function Model "Continuous Valve Actuator"

2.1.1 Aims and objectives

This object is used to control continuous actuating valve positioners e.g. for hot water heating radiators.

2.1.2 Functional specification

This ObIS controls the position of a valve positioner depending on the input signal „Continuous Actuating Value “ (%) and under consideration of the optional inputs „Manual Override Enable“, „Manual Override Value“ „Forced Position Enable “ and „Forced Position“. The CVA status information and the „Position Status“ are optional outputs.

2.1.3 Constraints

No constraints are defined for the ObIS Continuous Valve Actuator.

2.1.4 Functional Block

<u>Input(s)</u>		Continuous Valve Actuator		<u>Output(s)</u>	
Continuous Actuating Value	5.001 ----- See 3.1	CAV	PS	5.001 ----- See 3.2	Position Status
Manual Override Enable	-----	MOE	CVAS	-----	CVA Status
Manual Override Value	5.001 ----- See 3.1	MOV			
Forced Position Enable	-----	FPE			
<u>Parameter(s)</u>					
Position of deenergized Valve	See 3.1 -----	PDV			
Min Actuating Value	5.001 -----	MINAV			
Max Actuating Value	5.001 -----	MAXAV			
Actuating Value at Timeout	5.001 ----- See 3.3	AVT			
Timeout Period	-----	TP			
Forced Position Value	5.001 ----- See 3.3	FPV			
Period for valve Protection	-----	PVP			
Transmit CVA Status on Change	1.003 -----	TCVASC			
Enable	-----				
Transmit Cycle Time	See 3.3 -----	TCTCVA			
CVA Status	-----				
Delta Transmit Position Status	See 3.3 -----	DTPS			
Transmit Cycle Time Position	See 3.3 -----	TCTPS			
Status	-----				

2.1.4.1 Priority of the inputs

The value that is used for positioning is controlled by the Inputs “Manual Override Enable” and “Forced Position Enable”. The priority of these Inputs is shown in the table below.

Table 1 – Priority rules for the ObIS CVA

Manual Override Enable MOE	Forced Position Enable FPE	Used value for positioning
0	0	Continuous Actuating Value CAV
0	1	Forced Position Value FPV
1	0	Manual Override Value MOV
1	1	Manual Override Value MOV

2.1.5 Properties

ID	Name	Abbr.	Description	Datapoint Type	M/O
1	PID_OBJECT_TYPE		Object Type	KNX_Prop Data_Type	M

Input(s)

ID	Name	Abbr.	Description	Datapoint Type	M/O
<tbid>	PID_VALUE_ACTUATING_-CONTINUOUS	CAV	Continuous Actuating Value	5.001	M
<tbid>	PID_OVERRIDE_MANUAL_ENABLE	MOE	Manual Override Enable	See 3.1	O
<tbid>	PID_OVERRIDE_VALUE_MANUAL	MOV	Manual Override Value	5.001	O
<tbid>	PID_POSITION_FORCED_ENABLE	FPE	Forced Position Enable	See 3.1	O

Output(s)

ID	Name	Abbr.	Description	Datapoint Type	M/O
<tbid>	PID_STATUS_POSITION	PS	Position Status	5.001	O
<tbid>	PID_STATUS_CVA	CVAS	CVA Status	See 3.2	O

Parameter(s)

ID	Name	Abbr.	Description	Datapoint Type	M/O
<tbid>	PID_POSITION_VALVE_-DEENERGIZED	PDV	Position of deenergized valve	See 3.1	O
<tbid>	PID_VALUE_ACTUATING_MINIMUM	MINAV	Minimum Actuating Value	5.001	O
<tbid>	PID_VALUE_ACTUATING_MAXIMUM	MAXAV	Maximum Actuating Value	5.001	O
<tbid>	PID_PERIOD_TIMEOUT	TP	Timeout Period	See 3.3	O
<tbid>	PID_VALUE_ACTUATING_TIMEOUT	AVT	Actuating Value at Timeout	5.001	O
<tbid>	PID_VALUE_POSITION_FORCED	FPV	Forced Position Value	5.001	O
<tbid>	PID_PERIOD_PROTECTION_VALVE	PVP	Period for Valve Protection	See 3.3	O
<tbid>	PID_TRANSMIT_CHANGE_CVA_STATUS	TCVASC	Transmit CVA Status Change Enable	1.003	O
<tbid>	PID_CYCLE_TIME_TRANSMIT_CVA_STATUS	TCTCVA	CVA Status Transmit Cycle Time	See 3.3	O
<tbid>	PID_TRANSMIT_DELTA_STATUS_POSITION	DTPS	Delta Transmit Position Status	See 3.3	O
<tbid>	PID_CYCLE_TIME_TRANSMIT_STATUS_POSITION	TCTPS	Position Status Transmit Cycle Time	See 3.3	O

2.1.5.1 Property PID_VALUE_ACTUATING_CONTINUOUS

CAV

Unit: %
 Range: 0 ... 100
 Default Value: -
 Communication Object/Parameter: C
 Input/Output: I
 R/W Rate >> 10/day
 Description: This value is the positioning input value in percent.

2.1.5.2 Property PID_OVERRIDE_MANUAL_ENABLE**MOE**

Unit	-
Range:	0,1
Default Value:	0
Communication Object/Parameter:	C
Input/Output:	I
R/W Rate	< 1/day
Description:	This object serves to switch over from automatic mode (0) to manual mode (1). In manual mode the input Manual Override Value MOV is used for positioning instead of the „Continuous Actuating Value“ CAV. See 3.1

2.1.5.3 Property PID_OVERRIDE_VALUE_MANUAL**MOV**

Unit	%
Range:	0 .. 100
Default Value:	-
Communication Object/Parameter:	C
Input/Output:	I
R/W Rate	< 1/day
Description:	If the Manual Override Enable is set (MOE = 1) the „Manual Override Value“ MOV is used for positioning instead of the „Continuous Actuating Value“ CAV

2.1.5.4 Property PID_POSITION_FORCED_ENABLE**FPE**

Unit:	-
Range:	0,1
Default Value:	0
Communication Object/Parameter:	C
Input/Output:	I
R/W Rate	< 1/day
Description:	This communication object is used to force the valve positioner to the pre-programmed „Forced Position Value“ FPV.

2.1.5.5 Property PID_STATUS_POSITION**PS**

Unit:	%
Range:	0..100
Default Value:	-
Communication Object/Parameter:	C
Input/Output:	O
R/W Rate	>> 10/day
Description:	This object contains the actual value of the valve positioner.

2.1.5.6 Property PID_STATUS_CVA**CVAS**

Unit:	-
Range:	(coding: see 3.2)
Default Value:	-
Communication Object/Parameter:	C
Input/Output:	O
R/W Rate	>> 10/day
Description:	CVA status (coding: see 3.2) is an optional communication object which is read only.

2.1.5.7 Property PID_POSITION_VALVE_DEENERGIZED**PDV**

Unit: -
Range: 0,1
Default Value: free
Communication Object/Parameter: P
Input/Output: R/W
R/W Rate << 1/day
Description: This parameter defines the direction of control action of the valve positioner. The parameter must be set to „0“ if the valve is deenergized closed. It must be set to „1“ if the valve is deenergized open.

2.1.5.8 Property PID_VALUE_ACTUATING_MINIMUM**MINAV**

Unit: %
Range: min 0 ... 50
Default Value: 0
Communication Object/Parameter: P
Input/Output: R/W
R/W Rate << 1/day
Description: If the actuating value is less than MINAV the valve positioner either remains to position „0 %“.or goes to position „0 %“. This parameter is used to adapt the valve positioner to the valve.

2.1.5.9 Property PID_VALUE_ACTUATING_MAXIMUM**MAXAV**

Unit: %
Range: min 51 ... 100
Default Value: 100
Communication Object/Parameter: P
Input/Output: R/W
R/W Rate << 1/day
Description: If the actuating value is greater than MAXAV the connected valve either remains to position „100%“.or goes to position „100%“. This parameter is used to adapt the valve positioner to the valve.

2.1.5.10 Property PID_PERIOD_TIMEOUT**TP**

Unit: min
Range: 0; 1 ... 60
Default Value: free
Communication Object/Parameter: P
Input/Output: R/W
R/W Rate << 1/day
Description: This parameter defines the time during which at least one actuating value must have been received; else AVT is used instead of CAV

2.1.5.11 Property PID_VALUE_ACTUATING_TIMEOUT**AVT**

Unit:	%
Range:	0 ... 100
Default Value:	free
Communication Object/Parameter:	P
Input/Output:	R/W
R/W Rate	<< 1/day
Description:	This parameter is used as actuating value if no „Continuous Actuating Value“ CAV has been received during the timeout period.

2.1.5.12 Property PID_VALUE_POSITION_FORCED**FPV**

Unit:	%
Range:	0 ... 100
Default Value:	free
Communication Object/Parameter:	P
Input/Output:	R/W
R/W Rate	<< 1/day
Description:	This parameter is used as actuating value if the „Forced Position Enable“ FPE object is set.

2.1.5.13 Property PID_PERIOD_PROTECTION_VALVE**PVP**

Unit:	d
Range:	0; 1 ... 7
Default Value:	free
Communication Object/Parameter:	P
Input/Output:	R/W
R/W Rate	<< 1/day
Description:	This parameter defines the time during which at least two different actuating value must have been received; otherwise the valve protection will be activated. It will not be activated if PVP is set to “0”.

2.1.5.14 Property PID_TRANSMIT_CHANGE_CVA_STATUS**TCVASC**

Unit:	-
Range:	0,1
Default Value:	free
Communication Object/Parameter:	P
Input/Output:	R/W
R/W Rate	<< 1/day
Description:	This parameter defines whether the „CVA Status“ CVAS is transmitted on change or not.

2.1.5.15 Property PID_CYCLE_TIME_TRANSMIT_CVA_STATUS**TCTCVA**

Unit:	min.
Range:	0; 15 ... 60
Default Value:	free
Communication Object/Parameter:	P
Input/Output:	R/W
R/W Rate	<< 1/day
Description:	The CVA Status will be transmitted cyclically after the given cycle time. It will not be transmitted cyclically if the cycle time is set to “0”.

2.1.5.16 Property PID_TRANSMIT_DELTA_STATUS_POSITION**DTPS**

Unit:	%
Range:	0..25
Default Value:	free
Communication Object/Parameter:	P
Input/Output:	R/W
R/W Rate	<< 1/day
Description:	The „Position Status“ PS will be transmitted automatically if the difference between the last transmitted PS and the current PS is greater than the given delta value. It will not be transmitted automatically if the DTPS is set to “0”.

2.1.5.17 Property PID_CYCLE_TIME_TRANSMIT_STATUS_POSITION**CTPS**

Unit:	min.
Range:	0; 15 ... 60
Default Value:	free
Communication Object/Parameter:	P
Input/Output:	R/W
R/W Rate	<< 1/day
Description:	The „Position Status“ PS will be transmitted cyclically after the given cycle time. It will not be transmitted cyclically if the cycle time is set to “0”.

3 Datapoint Type(s)

3.1 Datapoint Type “Boolean”

<u>Format:</u>	1 bit
	<div>V</div>
<u>Encoding</u>	See below
:	
<u>Range:</u>	V = {0,1}
<u>Unit:</u>	-

Datapoint Types			
<u>Code:</u>	<u>Symbol:</u>	<u>Encoding:</u> V = 0	V = 1
1.003	FPE (Forced Position_Enable)	disable	enable
1.003	MOE (Manual_Override_Enable)	disable	enable
1.009	PDV Position of Deenergized Valve	closed	open
1.003	TCVASC Transmit_On_Change_Enable	disable	enable

3.2 Datapoint Type "CVA Status"

<u>Format:</u>	1 octet	
	<div>000EDCBA</div>	
<u>Encoding:</u>	See below	
<u>Range:</u>	A ...H = {0,1}	
<u>Unit:</u>	-	
Datapoint Types		
<u>Code:</u>	<u>Symbol:</u>	<u>Encoding:</u>
<tbd>	<tbd>	A : 0 = automatic; 1 = manual B: 0 = unforced position; 1 = forced position C: 1 = timeout actuating value active D: 1 = malfunction of the valve positioner E: 0 = Valve closed 1 = not closed

3.3 Datapoint Type "8-bit unsigned multiplier with special function for zero"

<u>Format:</u>	1 octet			
	<div>VVVVVVVV</div>			
<u>Encoding:</u>	See below			
<u>Range:</u>	V = [0...255] binary encoded			
<u>Unit:</u>	See below			
Datapoint Types				
<u>Code:</u>	<u>Symbol:</u>	<u>Encoding:</u>	<u>Range:</u>	<u>Unit:</u>
<tbd>	<tbd>	"time"	1...255 0 = corresponding function disabled	1 min
<tbd>	<tbd>	„time for valve protection“	1...255 0 = corresponding function disabled	1 d
<tbd>	<tbd>	percent	1..100 0 = corresponding function disabled	%